Practical Aim:- Interface with an Accelerometer Gyro Mpu6050 on the i2c bus and send sensor values over the internet via mqtt.

The Gyro Meter look like this:-



## Measuring Rotation and acceleration with the Raspberry Pi:-


Acceleration and rotation sensors are most known from smartphones. The rotation of the device can be detected and can be addressed directly. With the Raspberry Pi and a Gyroscope / Accelerator sensor it is possible to measure the rotation as well as the acceleration of the 3 axes.

## Setup

Raspberry Pi	MPU 6050
Pin 1 (3.3V)	VCC
Pin 3 (SDA)	SDA

Pin 5 (SCL)	SCL
Pin 6 (GND)	GND

The practical thing about I2C is that very few pins are used. Of the eight pins of the sensor, we only need to connect the upper 4:



## Activate I<sup>2</sup>C on the Raspberry Pi

First we enable SPI and I2C. If you have already done this in a previous tutorial, you can skip this step. sudo raspi-config

We then edit the modules file:

```
sudo nano /etc/modules
```

If the following lines are not already included, add them and restart the Pi (sudo reboot):

Shell

1 i2c-bcm2708

2 i2c-dev

Now we can quickly install the necessary tools:

```
sudo apt-get install i2c-tools python-smbus
```

Let's start a small test. The parameter -y 1stands for revision 2. If you have a completely old Pi (before 2013), you would have to specify a 0 instead:

```
sudo i2cdetect -y 1
```

If the gyroscope is properly connected, you will see this output (if you have other I2C modules connected, their hex addresses should be displayed):

```
70: -- -- -- -- --
```

To address the device with address 68 (Attention: Hexadecimal) under the register, enter the following:

```
sudo i2cget -y 1 0x68 0x75
```

## Read the MPU-6050 Modul

The most convenient way to read the acceleration sensor is probably Python. Therefore, we create a file and paste the following code.

```
sudo nano gyro.py
#!/usr/bin/python
import smbus
import math
# Register
power_mgmt_1 = 0x6b
power_mgmt_2 = 0x6c
def read_byte(reg):
  return bus.read_byte_data(address, reg)
def read_word(reg):
  h = bus.read_byte_data(address, reg)
 I = bus.read_byte_data(address, reg+1)
  value = (h << 8) + 1
  return value
```

```
def read_word_2c(reg):
  val = read_word(reg)
  if (val >= 0x8000):
    return -((65535 - val) + 1)
  else:
    return val
def dist(a,b):
  return math.sqrt((a*a)+(b*b))
def get_y_rotation(x,y,z):
  radians = math.atan2(x, dist(y,z))
  return -math.degrees(radians)
def get_x_rotation(x,y,z):
  radians = math.atan2(y, dist(x,z))
  return math.degrees(radians)
bus = smbus.SMBus(1) # bus = smbus.SMBus(0) fuer Revision 1
address = 0x68
                # via i2cdetect
# Aktivieren, um das Modul ansprechen zu koennen
bus.write_byte_data(address, power_mgmt_1, 0)
print "Gyroskop"
```

```
print "----"
gyroskop_xout = read_word_2c(0x43)
gyroskop_yout = read_word_2c(0x45)
gyroskop zout = read word 2c(0x47)
print "gyroskop_xout: ", ("%5d" % gyroskop_xout), " skaliert: ", (gyroskop_xout / 131)
print "gyroskop_yout: ", ("%5d" % gyroskop_yout), " skaliert: ", (gyroskop_yout / 131)
print "gyroskop zout: ", ("%5d" % gyroskop zout), " skaliert: ", (gyroskop zout / 131)
print "Beschleunigungssensor"
print "-----"
beschleunigung_xout = read_word_2c(0x3b)
beschleunigung_yout = read_word_2c(0x3d)
beschleunigung_zout = read_word_2c(0x3f)
beschleunigung_xout_skaliert = beschleunigung_xout / 16384.0
beschleunigung_yout_skaliert = beschleunigung_yout / 16384.0
beschleunigung zout skaliert = beschleunigung zout / 16384.0
print "beschleunigung_xout: ", ("%6d" % beschleunigung_xout), " skaliert: ",
beschleunigung_xout_skaliert
print "beschleunigung_yout: ", ("%6d" % beschleunigung_yout), " skaliert: ",
beschleunigung_yout_skaliert
print "beschleunigung_zout: ", ("%6d" % beschleunigung_zout), " skaliert: ",
beschleunigung_zout_skaliert
print "X Rotation: ", get_x_rotation(beschleunigung_xout_skaliert, beschleunigung_yout_skaliert,
beschleunigung zout skaliert)
```

print "Y Rotation: ", get\_y\_rotation(beschleunigung\_xout\_skaliert, beschleunigung\_yout\_skaliert, beschleunigung\_zout\_skaliert)

Save it with CTRL + O and exit the editor with CTRL + X. You can then run the script.

```
sudo python gyro.py
```

Now you'll see an output that contains all the captured data: